

Standard load service interval : 40,000km per interval

Item	Assembly	Description	2,000 KM - 4.000KM / 2 months	10,000KM / 130,000KM / 250,000KM	20,000km / 140,000KM / 260,000KM	30,000KM / 150,000KM / 270,000KM	40,000KM / 160,000KM / 280,000KM	50,000KM / 170,000KM / 290,000KM	60,000KM / 180,000KM / 300,000KM	70,000KM / 190,000KM / 310,000KM	80,000KM / 200,000KM / 320,000KM	90,000KM / 210,000KM / 330,000KM	100,000KM / 220,000KM / 340,000KM	110,000KM / 230,000KM / 350,000KM	120,000KM / 240,000KM / 360,000KM
1	Engine	Engine oil	I	I	I	I	C	I	I	I	C	I	I	I	C
2		oil filter	I	I	I	I	C	I	I	I	C	I	I	I	C
3		fuel filter	I	I	I	I	C	I	I	I	C	I	I	I	C
4		secondary fuel filter	I	I	I	I	C	I	I	I	C	I	I	I	C
5		Fuel/Water separator	I	I	I	I	C	I	I	I	C	I	I	I	C
6		Air cleaner	I	I	I	I	C	I	I	I	C	I	I	I	C
7	Transmission	Transmission lubricant ( ZF )	I	I	I	I	I	I	I	I	I	I	I	I	C
8	Drive Axle	Main reducer lubricant	C	I	I	I	C	I	I	I	C	I	I	I	C
9		hub reduction lubricant	C	I	I	I	C	I	I	I	C	I	I	I	C
10	power steering	Steering gear oil	I	I	I	I	I	I	I	I	I	I	I	I	C
11	Chassis	Chassis Grease	T	T	T	T	T	T	T	T	T	T	T	T	T
12	Brake System	Air dryer	I	I	I	I	I	I	I	I	C	I	I	I	C

C -MEAN CHANGE , I - MEAN INDICATES INSPECTION

ZF TRANSMISSION MAINTENANCE MILEAGE : Manual transmission 120,000 kilometre , automatic transmission 240,000 kilometre

considering the service environment and load condition, the maintenance interval of heavy goods is halved

For standard loading service interval : 40,000KM , Heavy load service interval : 30,000KM

Average cost for service MYR 0.075 ,MYR 0.098

Heavy load service interval : 30,000km per interval

Item	Assembly	Description	2,000 KM - 4.000KM / 2 months	10,000KM / 130,000KM / 250,000KM	20,000km / 140,000KM / 260,000KM	30,000KM / 150,000KM / 270,000KM	40,000KM / 160,000KM / 280,000KM	50,000KM / 170,000KM / 290,000KM	60,000KM / 180,000KM / 300,000KM	70,000KM / 190,000KM / 310,000KM	80,000KM / 200,000KM / 320,000KM	90,000KM / 210,000KM / 330,000KM	100,000KM / 220,000KM / 340,000KM	110,000KM / 230,000KM / 350,000KM	120,000KM / 240,000KM / 360,000KM
1	Engine	Engine oil	I	I	I	C	I	I	C	I	I	C	I	I	C
2		oil filter	I	I	I	C	I	I	C	I	I	C	I	I	C
3		fuel filter	I	I	I	C	I	I	C	I	I	C	I	I	C
4		secondary fuel filter	I	I	I	C	I	I	C	I	I	C	I	I	C
5		Fuel/Water separator	I	I	I	C	I	I	C	I	I	C	I	I	C
6		Air cleaner	I	I	I	C	I	I	C	I	I	C	I	I	C
7	Transmission	Transmission lubricant ( ZF )	I	I	I	I	I	I	I	I	I	I	I	I	C
8	Drive Axle	Main reducer lubricant	C	I	I	C	I	I	C	I	I	C	I	I	C
9		hub reduction lubricant	C	I	I	C	I	I	C	I	I	C	I	I	C
10	Intermedia	Main reducer lubricant	C	I	I	C	I	I	C	I	I	C	I	I	C
11	transfer axle	hub reduction lubricant	C	I	I	C	I	I	C	I	I	C	I	I	C
12	power steering	Steering gear oil	I	I	I	I	I	I	I	I	I	I	I	I	C
13	Chassis	Chassis Grease	T	T	T	T	T	T	T	T	T	T	T	T	T
14		balance shaft lubricant oil	I	I	I	I	I	I	I	I	I	I	I	I	I
15	Brake System	Air dryer	I	I	I	I	I	I	C	I	I	I	I	I	C

C -MEAN CHANGE , I - MEAN INDICATES INSPECTION

ZF TRANSMISSION MAINTENANCE MILEAGE : Manual transmission 120,000 kilometre , automatic transmission 240,000 kilometre

considering the service environment and load condition, the maintenance interval of heavy goods is halved

For standard loading service interval : 40,000KM , Heavy load service interval : 30,000KM

Average cost for service MYR 0.075 ,MYR 0.098